
Chicken Vision Walkthrough


Peter Chacko, Team 3997 Screaming Chickens

How do I get from a camera to target tracking?




1. Know your targets!

The targets are retroreflective tape. Instead of light reflecting like off a mirror, light bounces directly back at the light source.



Other retroreflective materials






2. LED Ring. This lights up the target, so it can be easily identified.






3. Lower exposure, so only the brightest lights (the targets + little noise) are visible



Most of the image is black, so now only the targets and a few bright lights are visible to the camera!

Color filter (HSV)


We need to filter this image so only the targets are recognized. In order to do this, we employ a HSV (or color) threshold to highlight only the green targets. This turns the pixels white where green is found, but black everywhere else.



The image is smoothed to reduce noise

Find Groups of Pixels (Contours)

The computer vision library (OpenCV), finds groups of white pixels and calculates their coordinates, area, angle, etc...




Distinguishing between targets.

Since there are multiple strips of retroreflective tape, determining which ones to identify as targets is a challenge.



Look a little deeper

Targets are adjacent (next to each other) and form a peak. False targets form a "V"



How Chicken Vision addresses this.

Select two contours at a time (sorted from left to right):

If all these statements are true, then we found a target


- Contours are adjacent
- Left contour is tilted right
- Right contour is tilted left



We determined our targets. Now what?


Goal: Find the degrees needed to align with the target:

• Calculate Horizontal Angle (Yaw) of the center of the target from the camera




Using what we know + some properties of the camera, we can calculate yaw!

Using the horizontal focal length of the camera (which can be calculated with the horizontal field of view), we can use trigonometry to calculate yaw.




Credit: Team 254

Math Class! Similar Triangles + Tangents




Applying Math!



Booom! You did it!

You started from a raw image and now are tracking objects! With great power comes great responsibility:)



Resources

- Team 254 Vision Presentation: https://www.team254.com/documents/vision-control/
- WPILib Vision
 Resources: https://wpilib.screenstepslive.com/s/currentCS/m/vision/l/288983-target-in fo-and-retroreflection
- #ChickenVision: https://github.com/team3997/ChickenVision
- images from Google image, WPILib, 254